

Green Glue

Noiseproofing Sealant

INSTALLATION INSTRUCTIONS



PREPARE FOR APPLICATION

Make sure the surfaces that are to be sealed are clean. Cut a 1/4" hole in the tip of the tube with a utility knife. Screw nozzle tightly over the tip of the tube and cut a 1/4" hole in the tip of the nozzle. When your nozzle is cut, place the tube in a standard 28 ounce caulk gun to prepare for installation.

APPLY GREEN GLUE NOISEPROOFING SEALANT

A very common application of Noiseproofing Sealant is filling 1/8" to 1/4" gaps between drywall joints, and areas where the drywall meets the floor and ceiling. Other applications include spaces around electrical outlets, windows, doors, and light fixtures.

Apply 48 hours before painting to allow for drying time. Drywall mud can be applied directly over Green Glue Noiseproofing Sealant.



I Q G # \$ I V W U I E X W R U

TEXT HERE